



The S-Series Warmup wiring centre is designed to work with both S-Series Thermostats, 3iE energy-monitor thermostat, tempo thermostat and your heat source, i.e. boiler. The wiring centre can control up to 4 zones and connects room thermostats to their corresponding actuators.

When the wiring centre is in operation, 230v output will switch relevant zone actuators, underfloor heating pump and valve on. Each zone is indicated by individual LED's on the wiring centre

The wiring centre can be adapted either on a DIN rail or directly on a wall. (DIN rail mounting allows for a slave facility or a timer.)

## Features:

- Can control up to 4 zones. Additional zones can be added using Warmup's 4 or 6 zone extension units
- Has outputs for the underfloor heating valve and pump
- Designed to work with our S-Series thermostats, 3iE energy-monitor thermostat and tempo thermostat
- Can connect to 4 thermostats and a maximum of 4 actuators per thermostat
- Equipped with a pump relay

## Technical Data:

Power Supply:	230VAC
Protection Class:	IP30
Warranty	3-Year warranty

